Instruction Guide for Kick Bucket and Stand



Read the instructions and safety information in this manual before operating this product.



Table of Contents

Features	3
Instructions	4
Care and Maintenance	5

Read and understand these instructions before assembling or using the stainless steel kick bucket and stand set. If the kick bucket and stand set is not properly assembled, personal injury and damage to the kick bucket and stand set could result.

If components are damaged or missing, contact InnerSpace Customer Service (1-888-435-2256). Do not use substitute parts.



Features

- · Stainless steel frame
- · Perimeter bumper to protect walls
- Tip resistant
- 2" swivel casters

Product Number	Dimensions	Additional Features
SMKB13	14" H x 13 1/2" D	Removable 13-quart stainless steel basin





Assembly

Assembly, repair, and maintenance must be performed by qualified personnel only.

Carefully remove the kick bucket and stand from its packing material. Place the kick bucket in the stand as shown and carefully press downward until the kick bucket is fully seated in the stand.

Operation

- · Clean the bucket before and after each use.
- · Ensure all components are secure before each use.





The kick bucket and stand must be cleaned on a regular basis in order to prevent unnecessary damage to the stainless steel surface. When cleaning the kick bucket and stand, make sure to use the proper cleaning agents and cleaning materials.

Do not use the following materials on the stainless steel surfaces of the kick bucket:

- · Abrasive pads
- Scrapers
- Steel wool
- · Wire brushes

Do not use the following agents on the stainless steel surfaces of the kick bucket:

- · Hard water
- · Bleach or any products containing chlorine
- · Hydrochloric acid
- · Denatured alcohol

Always follow the manufacturer's directions for any chemicals used on the stainless steel surfaces of the kick bucket and stand.

Use the following cleaning materials and agents:

- · Soft, clean lint-free cloth
- · Distilled water
- · Distilled water with mild detergent
- · Cleaners approved for use on stainless steel

Cleaning a Kick Bucket and Stand

- Using a damp, lint-free cloth, and approved cleaner, wipe all stainless steel interior and exterior surfaces
 of the kick bucket, and all surfaces of the stand.
- Use a lint-free dry cloth to dry the kick bucket and stand or let it air dry. If air drying, make sure that the kick bucket and stand are completely dry before storing, and store only in dry conditions.

Decals or printed labels:

Use distilled water and a mild detergent applied with a lint-free cloth. Do not use any chemical cleaner.



The kick bucket and stand can become damaged and unsafe if used improperly.

Kick Bucket and Stand

- · Never overload the kick bucket stand.
- · Do not drop heavy loads on the kick bucket.
- · Do not use the kick bucket at high speeds.

Using the kick bucket in any of the above conditions can result in failure of the casters, wheels, or other parts of the equipment.

Periodically inspect the bottom of the kick bucket stand and look for any of the following:

- · Broken welds.
- · Loose nuts or bolts. These should be tightened.
- Frame distortion that could be caused by an overloaded bucket or by impacts with other objects while
 moving the bucket.

Casters and Wheels

- Make sure the casters are in good condition. If a swivel caster has excessive play due to wear, it may need to be replaced. If casters don't turn freely, corrosion or dirt may require their replacement.
- Wheels should be checked for visible tread wear. Flat spots due to accumulation of material, such as string or thread, can cause the wheel to bind. The axle bolt nut should be removed and the foreign material removed. If the internal components are intact, the caster can be reassembled.
- Rubber tires can be badly worn and cause erratic steering, bumping, load shifting, and floor damage.

