

# Attaching a Slope Top to Your Roam Supply Cart

Follow these steps to install a slope top on your Roam cart.

Tools needed:

- Phillips head screwdriver
- 5/64" Allen wrench

## Step 1

- Use screwdriver to remove the screws from the 4 corner trim pieces. There are 2 screws on each corner trim piece per corner for a total of 8 screws to be removed.

## Step 2

- Use Allen wrench to remove the 4 screws from the cart's existing flat top. Screws are located inside the cart on the underside of the top.

## Step 3

- Remove the top by lifting straight up and off.

## Step 4

- Set the slope top on top of the cart.

## Step 5

- Secure the slope top to the cart from the inside of the cart with the 4 screws.

## Step 6

- Reattach the 4 corner trim pieces with the 2 screws per trim piece (total of 8 screws).

