
Evolve Door Hinge Adjustment

Follow these instructions to adjust the Evolve cabinet door's horizontal, vertical, and depth positions.

Tools needed:

Phillips screwdriver





To adjust horizontally


Step 1

• Open the door to access the hinge screw on the front of the hinge.

Step 2

• Using the screwdriver, loosen or tighten to adjust the door to the correct location.





To adjust vertically


Step 1

• Using the screwdriver, loosen the screw on the door mounting plate.

Step 2

• Adjust the door up or down to the correct location and tighten.





To adjust depth

Step 1

• Using the screwdriver, loosen to adjust the door depth.

