



Removing and Replacing a Manifold Tube or Manifold Auxiliary Water Tube

Follow these instructions to remove and replace the manifold tube or manifold auxiliary water tube in the Ventaire drying and tracking system.



To remove

Turn the tube fitting to the left to loosen and remove the tube from the manifold



To replace

To replace the tube, insert a new tube and turn the hose fitting to the right until the tube is firmly attached to the manifold

