Removing and Replacing Air Filter

Ventaire[™] Endoscopy System

Instructions for Scope Drying Unit

Follow these instructions to remove and replace the air filter on the scope drying unit.

To remove:

Press the quick release buttons on the top and bottom of the air filter, and pull out and discard the filter

To replace:

Insert the new air filter. The quick release buttons will reset once the filter is attached



